

PRIMER 1000

Technical Sheet

NAME:

TYPE:

USE:

COMPOSITION:

CHARACTERISTICS:

PRIMER 1000

water-based primer

light grey water-based primer for indoor easy to apply.

special resins and charges allowing breath-

specific weight: 1.465 ± 30 gr/LT. at 20°C

yield: 14 - 15 m²/LT. for a coating (it may vary according to the roughness, surface absorption and application methods)

stability: 24 months, stock between +5°C and +30°C

colours: light grey

packaging: LT. 0,500 - LT. 1

on the surface 2 hours at 20°C

overpainting : 4 - 6 hours at 20°C

in depth: 24 hours at 20°C

DRYING:

CHARACTERISTICS AND RESISTANCE:

grey water-based primer necessary to get the decorative effects of Klondike Light. Primer 1000 is easy to apply and it is characterised by a good covering, resistance and washability. It can be applied on several surfaces as cement, plaster, plaster of Paris, plasterboard, wood and iron and even on surfaces that have already been painted (provided that the existing coat is not peeling)

dilution: ready to use

PREPARATION OF THE

PRODUCTS:

APPLICATION:

system: by brush-by roller-by spray

number of coatings: 1 - 2 or more to cover

PREPARATION OF THE

SURFACE:

Old walls. Remove old non-adhering and peeling paint and wash using water and a suitable soap product. Next, apply a fixative suited to the type of surface. When the fixative is completely dry, apply a coat of Primer 1000 and, after 6 hours at 20°C, proceed with the application of Klondike Light.

New walls. Clean (and if necessary, fill) the surface you wish to paint. Once it is dry, sand the surface and apply a coat of suitable fixative. When the fixative is completely dry, apply a coat of Primer 1000 and, after 6 hours at 20°C, proceed with the application of Klondike Light.

Wood, glass, light alloys and painted iron. Remove all grease from the surface and sand well, so that it is smooth and clean. Apply a coat of primer which is suited to that particular type of surface, then apply a coat of Primer 1000. After 6 hours at 20°C, proceed with the application of Klondike Light.

New iron (not treated). Remove all grease and any layers of rust from the surface and apply one coat (or more) of a suitable anti-rust treatment. When this is completely dry, apply a coat of Primer 1000 and, after 6 hours at 20°C, proceed with the application of Klondike Light.



VALPAINT S.p.A.
Via dell'Industria, 80 - 60020 POLVERIGI (AN) ITALY
Tel. +39 071 906383 (r.a.) - Fax +39 071 906384
E-mail: info@valpaint.it
C.F./P.IVA/R.I. di AN 01108220425
Capitale Sociale € 500.000,00 i.v.

www.valpaint.it

SC 00219

NOTES:

Temperature of application must be between +5°C and +30°C. Wash the tools soon after use with water and soap.

Technical Sheet n° SC 00233 issued by the Responsible Quality Control:

Edition n° 1

December 2011

page 2 of 2